# DOMUS®

29–31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au www.domuslighting.com.au

## Installation Manual

February 27, 2024 3:14 PM

# DEEP-12

Variants							
Blk	Wht	— Item No.	Colour Temp				
21731	21732	DEEP-12	TRIO				

Description: Deepset LED Downlight


Thank you for purchasing your new DEEP-12 downlight, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

### Specifications

Voltage:	240V AC	Lumen (±5%):	Warm White 3000K - 1174lm Neutral White 4000K - 1289lm White 5000K - 1202lm	Dimmable:	Yes
Power:	12W	Beam Angle:	60°	Operating Temp:	-20°C~45°C
IP Rating:	IP40	CCT:	3000K - 4000K - 5000K (Switchable)		
CRI:	≥90	Lifespan:	50,000Hrs		


#### Step 1

Open a hole according to the cutout size of led downlight.




#### Step 3

Connect the downlight with driver, hold back the spring clip the push the downlight into the hole.




#### Step 2

Use screw-driver to open the driver terminal cover, feed the main AC wire LN in terminal block respectivley, then fix the cover back,



#### Step 4

Connect the downlight with driver, hold back the spring clip then push the downlight into the hole.



Note: -The lamp must be installed by professional electrician -Ensure the power supply is switched off before fitting this product