

Installation Manual

March 27, 2024 10:48 AM

PANEL-606-BLT


Thank you for purchasing your new LED PANEL-606-BLT, Please take the time to read and understand the instruction sheet below. Failure to do so may void warranty.

Specifications


Voltage:	240V	Lumen ($\pm 5\%$):	Warm White - 3500lm Neutral White - 3600lm White - 3550lm	Dimmable:	No
Power:	30W	Lifespan:	40,000hrs	Operating Temp:	-20°C~45°C
IP Rating:	20	CCT:	3000K - 4000K - 5700K (switchable)	Power Factor:	≥ 0.9
CRI:	≥ 80				

Suspending: Mounting clips and suspension kits are required - (sold separately)


Recessed into ceiling




1. Remove ceiling plaster tile.



2. Connect power supply.




3. Fix the panel light into the right place.




4. Stabilise the panel.


Suspending




1. Fix the anchor into target place on the ceiling.



2. Fix the installation mount on the ceiling with plastic anchor.




2. Hang the panel to ceiling with suspended installation kits.




3. Adjust the length of steel wire. Connect the power supply.


Surface Mounted




1. Fix the frame onto the ceiling except plaster ceiling.




2. Insert plug of panel into mains socket.




3. Slightly tilt and insert the panel into one side of the frame



4. Move the panel into the other side of the frame



5. Insert the plastic plugs into the 4 holes to keep the panel stable.



6. Turn on the main power supply

Note: -The lamp must be installed by professional electrician
-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use
-Keep away from hot steam and corrosive gas