

29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

Date: March 8, 2024 9:54 AM

SUNSET-300-RND-EM-SEN

Specifications

all and the same a						
Voltage:	240V AC	Lumen (±5%): Warm White 3000K - 2160lm		Dimmable:	No	
		Neutral White 4000K - 2250lm White 5700K - 2410lm	D	Yes		
Power:	25W	Beam Angle:	120°	Operating Temp:	25°C	
IP Rating:	IP54	CCT:	3000K - 4000K - 5700K	Class:	Class II	
CRI:	≥80	Lifespan:	50,000hrs			

WARNING

- Switch OFF before installation
- Switch on only after complete installation and exminations of the circuit.
- Professional Electrician required for installation and maintenance only.






Turn off power supply before starting any installation. Read instructions & check that you have all the tools & accessories to complete the installation properly.






Take out the ceiling light and accessory pack from box.









Remove the screws and take out the bracket. CCT switchable function: Choose CCT by slide switch before mounting to ceiling/wall.





Knock the plastic anchor into ceiling and fix bracket with screw into the ceiling.





Remove the driver cover and line pressing, connect the wires correspondingly. (If emergency function, open the battery cove and connect the plugs). Then Switch

Note:

- -The lamp must be installed by professional electrician
- -Ensure the power supply is switched off before fitting this product
- -Do not touch the lamp when in use
- -Keep away from hot steam and corrosive gas




29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

Wiring Diagram



Sensor Diagram

Factory Settings

Detection Area	Hold Time	Stand-by Period	Stand-by DIM Level	Daylight Threshold
100%	5s	Os	10%	Disable



Key	Key Function	Key Function Illustration
ON/OFF	ON/OFF	Turn OFF the lamp, sensor function will stop. Turn ON, sensor function will start and keep the same lighting parameters from last operation.
\$ 14 C	Night-Light	3% Standby
Dim+	Brightness +	5% Increase step by step
Dim-	Brightness -	5% Decrease step by step
Standby Dim Level	Standby Dim Level	10%, 30%
Hold Time	Hold Time:	5s, 1min, 5min, 10min
Detection Area	Detection Area	100%, 75%, 50%, 25%
Stand-by Period	Stand-by Period	0s, 1min, 10min, + ∞
TEst	Test	Press test, lamp will be turned off after 2 seconds. It will keep the same parameter as last operation when turned on.
Daylight Threshold	Daylight Threshold	15Lux 🚟 , 50 Lux 🚉 , Disable.

Note:

-The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use

-Keep away from hot steam and corrosive gas



29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au

Installation Manual

Spec of Sensor

Power	<0.15W
Input Rated Voltage	7.5V
Input Voltage	12V
Current	<25mA
Output	PWM
Microwave Function	ON/OFF (Optional)
Dimming Range	0% - 100%
Detection Distance	Near 2-4m / Medium 4-6m / Far 5-9m (Optional)
Daylight Lux	OFF / 50-100lux (Dusk) / 10-15lux (Night) (Optional)
Keep Brightness	OFF / 10% / 20% / 30% (Optional)

Indicators Model

Green Indicator	Charge End
Yellow Indicator	Battery Charging
Red Indicator	In emergency status
Green + Yellow Indicators Flashing	Battery Fault
Green + Yellow Indicators OFF	Battery Over Temperature



Indicator Guide

- A. Inspection Button
- B. Green Indicator
- C. Yellow Indicator
- D. Red Indicator