

29-31 Richland St. Kingsgrove. Sydney NSW 2208 Australia Phone: 02 9554 9600 | Fax: 02 9554 9433

enquiries@domuslighting.com.au | www.domuslighting.com.au


Installation Manual


Date: April 26, 2024 3:28 PM


TACK-8-WHT

Specifications

| Voltage: | 240V AC | Lumen (±5%): | Warm White 3000K - 750lm Neutral White 4000K - 800lm White 5700K - 780lm | Dimmable: | Yes |
|------------|---------|--------------|--|-----------------|------------|
| Power: | 8W | Beam Angle: | 110° | Operating Temp: | -20 ~ 45°C |
| IP Rating: | 44 | CCT: | 3000K - 4000K - 5700K | Power Factor: | 0.9 |
| CRI: | ≥80 | Lifespan: | 35,000hrs | | |









Cut out a hole in the ceiling. Ensure there is sufficient clearance in the area where you will be positioning the fitting.

Choose the prefered colour temperature via the switch on the controller.

Connect the fitting to the mains via the power plug.





Fit the fixture in the ceiling by lifting the spring clips upwards.

Once in place the spring clips should be against the top of the ceiling and support the fitting.

Note:

-The lamp must be installed by professional electrician

-Ensure the power supply is switched off before fitting this product

-Do not touch the lamp when in use

-Keep away from hot steam and corrosive gas